

SLEEPER DIRECTIONS


Disclaimer: These instructions are guidelines. There may be alternate sewing methods.

Items in Sleeper Kit:



One sleeper back, two sleeper front panels with interfacing*, two sleeves and 8 " x 2 ½ " ribbing for collar.

*Interfacing is usually applied to the two front panel edges before sleeper kit is assembled.

Sleeper Back Panel




Sleeper Front Panels with interfacing applied



With right sides together, sew back and front panels to sleeves.



Sew sleeve cuff ribbing now while garment will lay flat.

Neck Ribbing Detail



The neck ribbing is sewn at an angle at the front opening and set back from the edge approximately $\frac{1}{2}$ ".

The ribbing is also captured in the front lapel fold.



Fold the front lapel back with right sides together.

Insert the beginning of the ribbing approximately $\frac{1}{2}$ " in from edge and at an angle. This makes the clean ribbing edge on the collar.

Sew collar ribbing around neck and repeat the angle and lapel fold on the other end.



Sew one long seam from one sleeve, around body and legs to other side and sleeve.


ARM PIT TIP

To avoid puckers in the arm pit, sew the area with some vertical tension so the sleeve seam and the body seam are almost one vertical line.

Vertical Tension





Don't sew angled seam like this



SEWING CROTCH

Fold both lapels back. Lay one on top of the other and sew into the crotch seam. Pin this carefully – it will be a thick seam. Lay left over right or right over left. Either way is OK.

Top stitch the lapels down. This provides more stability for the snaps later.



COMPLETED SLEEPER

* We will add the snaps ~~when~~ when the sewn sleeper is returned to us.